

0

Well done!

×2

10th

×8



床板支撑铁右

2×

R.

•

床板支撑铁左

<u>M10螺母</u>

**》** M10×30螺钉

M10×30螺钉

P

<u>M10螺母</u>

11th

## Hc738a assembly procedure (require3 workers)

Please take down the last two beds according to above method, and then cut the belt of the handset.